

A DIVISION OF GETZ FIRE EQUIPMENT

### GETZ EQUIPMENT INNOVATORS PART # 3G59338 TOTAL DUMP SYSTEM

(Revised 2/8/18)



2320 Lakecrest Drive, Pekin, Illinois 61554 Telephone: 888-747-4389 Fax: 309-495-0625 Website: www.getzequipment.com

# **Limited Warranty**

Products manufactured by Getz Equipment Innovators (with exception of electrical products or components) will be free from defects for a period of one year from shipment date. Electrical products and/or components used in manufactured products will have a (6) month warranty from shipment date. During the warranty period, customers who experience any manufacture-related service issues with our products, the product may be returned for repair or replacement. Customer must contact Getz Equipment for approval prior to any product return. Notwithstanding the foregoing, the limited warranty set forth shall be immediately void of customer uses any replacement parts other than those provided by Getz Equipment Innovators. The warranty does not cover normal wear and tear items, defects resulting from modification, alteration, misuse, exposure to corrosive conditions, extremely high temperatures, improper installation or maintenance. Warranties on component items not manufactured by Getz Equipment Innovators are provided by others whose warranty, evaluation and judgment will be final.

All implied warranties, including, but not limited to, warranties of fitness for purpose and merchantability, are limited to the time periods as stated above. In no event shall Getz Equipment Innovators be liable to incidental or consequential damages. Some states do not allow limitations on how long an implied warranty lasts or the exclusions or limitation of incidental or consequential damages, so that the above limitations or exclusions may not apply to you. Getz Equipment Innovators neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than as expressly set forth herein.

#### **Mobile Service Vehicles:**

The warranty does not cover:

- Defects in the chassis and or power unit
- Defects in separately manufactured products not produced by Getz Equipment Innovators
- Deterioration due to normal wear, tear, and exposure
- Repairs made necessary by negligent use, misuse, abuse, loading the service vehicle beyond its gross vehicle weight limitations, accident, acts of God, or other contingencies beyond the control of Getz Equipment Innovators.
- Repairs deemed necessary by reason of the failure to follow ordinary maintenance procedures.
- Repairs deemed necessary by reason of alterations done without Getz Equipment Innovators' written approval.

### Warranty Service:

- All warranty repairs will be performed by Getz Equipment Innovators in Pekin, IL, unless otherwise authorized by Getz Equipment Innovators.
  Freight:
- Getz Equipment Innovators will not be liable for shipping or transportation charges to or from customer's location.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. To obtain performance to the obligation of the warranty, write to Getz Equipment Innovators, 2320 Lakecrest Drive, Pekin IL 61554, USA for instructions.

## P/N 3G59338 TOTAL DUMP INSTALLATION/OPERATING INSTRUCTIONS

- 1. Lay a 50-pound bucket of chemical on the floor sideways, roll the bucket around to loosen the chemical.
- 2. Remove the plastic lid from the 50-pound bucket of chemical, place the Total Dump assembly on top of the 50-pound bucket of chemical. Align the assembly to fit flush on the rim of the bucket.
- 3. Align the clamp (item 7) around the rim of the bucket and total dump assembly. Fold the clamp lever inward toward the band of the clamp. The clamp should fit tightly around the rim of the bucket and the rim of the total dump assembly. If needed, with the clamp in the closed position, turn the adjustment screw on the clamp lever clockwise until the clamp becomes snug. DO NOT OVER TIGHTEN.
- 4. Place the fill cone (item 2) into the neck of the extinguisher or wheel unit as you invert the bucket upside down. The fill cone must seal fully inside the extinguisher neck to prevent chemical dust from escaping.

