

A DIVISION OF GETZ FIRE EQUIPMENT

# Getz Equipment Innovators Part No.: 3G59558 Water Reclaim Tank

**Revised 11-8-2017** 



2320 Lakecrest Drive, Pekin, Illinois 61554 Telephone: 888-747-4389 Fax: 309-495-0625 Website: www.getzequipment.com

### **Limited Warranty**

Products manufactured by Getz Equipment Innovators (with exception of electrical products or components) will be free from defects for a period of one year from shipment date. Electrical products and/or components used in manufactured products will have a (6) month warranty from shipment date. During the warranty period, customers who experience any manufacture-related service issues with our products, the product may be returned for repair or replacement. Customer must contact Getz Equipment for approval prior to any product return. Notwithstanding the foregoing, the limited warranty set forth shall be immediately void of customer uses any replacement parts other than those provided by Getz Equipment Innovators. The warranty does not cover normal wear and tear items, defects resulting from modification, alteration, misuse, exposure to corrosive conditions, extremely high temperatures, improper installation or maintenance. Warranties on component items not manufactured by Getz Equipment Innovators are provided by others whose warranty, evaluation and judgment will be final.

All implied warranties, including, but not limited to, warranties of fitness for purpose and merchantability, are limited to the time periods as stated above. In no event shall Getz Equipment Innovators be liable to incidental or consequential damages. Some states do not allow limitations on how long an implied warranty lasts or the exclusions or limitation of incidental or consequential damages, so that the above limitations or exclusions may not apply to you. Getz Equipment Innovators neither assumes nor authorizes any representative or other person to assume for it any obligation or liability other than as expressly set forth herein.

#### **Mobile Service Vehicles:**

The warranty does not cover:

- Defects in the chassis and or power unit
- Defects in separately manufactured products not produced by Getz Equipment Innovators
- Deterioration due to normal wear, tear, and exposure
- Repairs made necessary by negligent use, misuse, abuse, loading the service vehicle beyond its gross vehicle weight limitations, accident, acts of God, or other contingencies beyond the control of Getz Equipment Innovators.
- Repairs deemed necessary by reason of the failure to follow ordinary maintenance procedures.
- Repairs deemed necessary by reason of alterations done without Getz Equipment Innovators' written approval.

#### Warranty Service:

- All warranty repairs will be performed by Getz Equipment Innovators in Pekin, IL, unless otherwise authorized by Getz Equipment Innovators.
   Freight:
- Getz Equipment Innovators will not be liable for shipping or transportation charges to or from customer's location.

This warranty gives you specific legal rights, and you may also have other rights which vary from state to state. To obtain performance to the obligation of the warranty, write to Getz Equipment Innovators, 2320 Lakecrest Drive, Pekin IL 61554, USA for instructions.


#### Getz Equipment Innovators Water Reclaim Tank (3G59558)

#### **Table of Contents**

<u>Page</u>	
1	
2	Mounting and Installation Instructions
3	Mounting and Installation Instructions, Continued
4	

<u>Power Source:</u> A 120AC or power inverter if used in a mobile application

## Safety Requirements: Safety Glasses



#### **DRAWING 1**

ITEM	PART #	DESCRIPTION	QTY	ITEM	PART #	DESCRIPTION	QTY	
							•	
1	1G0032	Tubing ½ I.D. Clear Vinyl	8	11	1G0588	Threaded Bushing CPVC 1 ¼ x ½	1	
2	1G0033	Tubing ½ Reinforced Clear	3.5	12	1G51624	Pipe Elb Br ¼ St	4	
3	1G0041	Clamp 2 – Ear ¾"	9	13	1G51683	Pipe RDCR Br 3/8 x 1/4	4	
4	1G0064	Gauge Dry 0-160 PSI	1	14	1G53061	Pressure Relief Valve 40PSI	1	
5	1G0075	Barb Hose ½ MNPT x ½ Hose	1	15	1G54023	Filter Housing	2	
6	1G0076	Barb Hose ¼ MNPT x ½ Hose	6	16	1G54024	Water Filter Element	1	
7	1G0291	½ Brass Elbow M/F	1	17	1G54026	Water Filter Bracket	2	
8	1G0428	Brass Tee ¼	3	18	1G54097	Carbon Water Filter Element	1	
9	1G0502	Pump 120V Water Reclaim	1	19	1G54128	Plate Mnt Filter/Pump Wt	1	
10	1G0505	Tank 5 Gal Water Reclaim	1	20	1G54144	Plastic Bulkhead Fitting ¼	1	

#### **Mounting/Installation Instructions:**

1. Remove zip ties to free up the hoses and wiring.



**2.** Mount the red plate roughly 15 inches down from the bottom of the top plate on the stand, using supplied 5/16 head SDS screws. You will need to remove the filter housing to access the bottom mounting holes.









**3.** Connect the discharge hose of the tester to the hose barb on the right side of the water filter. You will need to cut the hose to fit length.







4. Connect the hose with the brass garden hose fitting to the water inlet of the tester





5. Mount switch plate to the top plate of the hydro tester.









**6.** Plug the pump into a 120V receptacle. Make sure the switch for the pump is in the off position.

#### **Operating Instructions:**

- 1. Fill water tank to the 5-gallon mark
- 2. To begin filling the cylinder, open all the valves on the tester and turn the switch on to start the water pump
- **3.** Once the cylinder is full, keep the water pump on and follow the operating procedures for the hydrostatic tester. Verify by checking the water level in the filter housing (Item 16).

#### **Maintenance Instructions:**

- 1. Check the water filter every week or approximately every 100 cylinders tested depending on water quality. You will need to change the standard filter (Item 16) every 6 months and the carbon filter (Item 18) every 12 months.
- 2. Do not leave or operate water tank in temperatures below 32° F

#### **Trouble Shooting**

<u>Issue</u>	Solution		
The pump is not operating	Verify the pump is plugged into a 120V outlet.		
	Make sure switch for pump is in the "on" position.		
	Check to see if the valve on the tester is closed, creating back pressure on the pump, shutting it off.		
No water flow to the cylinder	Check to see if the water tank is empty.		
	Check to see if the filters on the water tank are clogged.		